

Town Hall

Walls above second floor ceiling: Install mineral wool batt insulation (R-19) at perimeter walls for the space between the second-floor finish ceiling and attic floor. Insulation must be secured in place and installed tight.

Install 12" blown-in cellulose (R-30) within the attic floor framing. Remove existing decking as required to provide even coverage to the required depth.

Remove all flammable items stored in the attic & provide to the owner for use or dispose.

If any knob and tube wiring is encountered, confirm it is not active and remove it. Provide an allowance for this work.

